




SUPER L VI™ USER'S GUIDE



LARGE FORMAT DIGITIZERS



Table of Contents

Introduction	3
Parts Checklist	5
What You Will Need to Use Super L VI	5
PC Requirements	5
For a USB Installation	5
For an Optional Serial Installation	6
Super L VI Overview	6
Active Area	7
SuperSet Menu	7
Indicator Light	7
Transducer	7
Preparing the Super L VI	7
Mounting on a Stand	7
Attaching the Optional Accessory Tray or Plan Holder	8
Software Configuration	8
Configuring Non-Wintab Applications	8
Installing the TabletWorks Driver	8
Hardware Configuration	9
USB Connection	9
QuikRuler III	10
Transducer Connection	10
Optional RS-232 Serial Connection	10
Tablet Power On	11
Using the SuperSet Menu	11
Resetting the Super L VI	12
Turning the Alarm Off and On	12
Testing the Active Area	13
Configuring Your Super L VI for Specific Applications	13
Table 1: SuperSet Menu Codes for Selected Applications	14
Table 2: Configuration Details for SuperSet Menu Codes	24
Super L VI Tones	29
Table 3: Super L VI Tones	29
Introduction to the Tablet Configuration Utilities	29
Communication Options	30
Output Format Options	30
Mode Options	31
Using the Tablet Configuration Utilities	31
Learning the Basics	33
Using the Transducer	33
Using the Cursor	33



Using the Pen	34
Learning Basic Movements	34
Clicking and Double-Clicking	34
Dragging	34
Caring for the Tablet and Transducer	34
Cleaning the Tablet	34
Cleaning the Cursor	35
Replacing the Pen Tip	35
Replacing the Cordless Pen Batteries	36
Replacing the Cordless Cursor Batteries	36
Troubleshooting	37
Tablet Checklist	38
Computer Checklist	38
Software Checklist	39
Does the tablet work with some software?	39
Did the software work in the past?	39
Troubleshooting Chart	40
Procedure A: Begin Troubleshooting	41
Procedure B: Troubleshooting	42
Returning your Tablet for Repair	43
Repacking for Shipment	43
Regulatory Statements and Warranty	43
Radio and Television Interference	43
Canada	44
Japan	44
European Union Emission Directive	44
European Union WEEE Directive	45
Bescheinigung des Herstellers/Importeurs	45
Limited Warranty for the Super L VI	46

Introduction

Super L VI belongs to a class of computer input devices called **graphics tablets**, or **digitizers**. A digitizer is an electronic tablet work surface. The position of a transducer, a handheld cursor or stylus pen, on the work surface of the Super L VI is converted – digitized – into data for computer processing. Data output from the Super L VI digitizer is in the form of an X/Y coordinate pair that pinpoints the precise location of the transducer on the tablet surface. By placing a drawing or sketch on the tablet's surface and tracing over it, graphical information can be easily converted into accurate digital information for entry into the computer. Super L VI digitizers are the next generation of the Super L family of digitizers that set the standard in large-format digitizing. These high performance tools are engineered with a state-of-the-art



positioning grid to ensure reliability and quality. Professionals in construction, estimating, CAD, textiles and other fields appreciate the flexibility and performance of the Super L VI series.

The Super L VI family of large-format digitizers boasts resolutions of up to 2540 lines per inch, accuracy of 0.010 inch and a wide range of sizes, providing the perfect solution when the work demands precision data input over a large surface area. A variety of cordless and corded cursors and stylus pens are available to use with the Super L VI. An integrated mounting channel allows accessories, such as a plan holder, to be quickly and easily mounted. The high-productivity Super L VI can be used as both a digitizer and a mouse, eliminating the need for multiple devices at your computer.

Super L VI works with many graphic, CAD and estimation applications. These applications use the digitized data from Super L VI to:

- Determine the dimensions of objects on drawings and blueprints
- Move the pointer on the display screen
- Create and manipulate objects in a graphic composition
- Trace a drawing or other source material, to create an image on the screen
- Select commands or functions from an application menu placed on the tablet surface
- Select items from a pull-down menu on the screen

In order to send data from Super L VI to your digitizing application, the digitizer must be physically connected to your computer, and it must be able to transmit the data in such a way that the digitizing application recognizes and understands it.

Before setting up Super L VI, you should determine:

- The requirements of the digitizing software application you're using
- Whether your digitizing application requires software drivers to communicate with Super L VI
- The hardware communications connection (USB or Serial) you will be using between the Super L VI and the computer

When the Super L VI is set up for a serial connection, it must be configured so that it can send data in a way the application software will recognize and understand. Different applications have different requirements when interacting with a digitizer. The Super L VI has been designed to provide the appropriate serial requirements for a wide variety of graphic, CAD and estimating applications using a simple code system. The SuperSet Menu located at the top of the Super L VI is used to enter the appropriate code for the software you are using. Table 1 in the *Using the SuperSet Menu* section of this manual lists the SuperSet Codes for a wide variety of applications. All you have to do is input the code for the application you are using and the Super L VI will be able to communicate properly with the application software on your computer. Table 2 lists the configuration details for each SuperSet Code in Table 1.



If for some reason, the communication requirements for your software cannot be found in the two tables provided in the SuperSet Menu section, Tablet Configuration Utilities (visit our Website gtcocalcomp.com) can be used to configure your Super L VI so it has the appropriate information it needs to communicate successfully with your software.

Parts Checklist

- ✓ Super L VI digitizing tablet
- ✓ Transducer (corded or cordless pen, 4-button or 16-button cursor)
- ✓ USB cable
- ✓ Warranty Sheet

Optional Equipment

- ✓ RS-232 with 9-pin connector for serial connection
- ✓ Power supply – required only for a serial installation
- ✓ Universal mounting brackets
- ✓ Table feet
- ✓ Accessory tray
- ✓ Plan holder

What You Will Need to Use the Super L VI

Super L VI is equipped with both a USB interface and an RS-232 serial interface, which requires an optional RS-232 cable and power supply. It is compatible with most industry-standard PCs. The TabletWorks driver by GTCO CalComp is the only software described in this manual. TabletWorks supports Wintab and TabCon-compatible applications. If you are not sure which drivers are required, please consult with your application vendor.

A USB connection requires the use of a TabletWorks driver, while a serial connection requires the use of a TabletWorks driver and/or a custom application program. After installing the TabletWorks software, the Super L VI will work with all Windows-based applications as a mouse, in addition to working as a digitizer with Windows-based applications that are specifically designed for use with digitizers.

PC Requirements

For a USB Installation

- Microsoft Windows 7,8 or 10
- One available USB port
- 10 MB of free disk space
- Application software that accepts digitizer input via the Wintab API or TabCon API




For an Optional Serial Installation

- Microsoft Windows 7, 8 or 10
- One available RS-232C serial communication port (Serial signal levels must conform to EIA RS-232C specifications.)
- 10 MB of free disk space
- Application software that directly accepts digitizer input via the computer's RS-232C serial port, or via the Wintab API or TabCon API

Overview

The Super L VI consists of: 16B or 4B cursor. Corded or Cordless Pen (stylus). Digitizer.





Indicator Light

Active Area

The drawing area – the Active Area – is the portion of the tablet surface designated for digitizing. Its boundaries are marked at each corner by a right-angle crop mark.

SuperSet Menu

The SuperSet Menu is the row of keys located across the top of the digitizer. It provides a means of configuring your tablet so that it sends the appropriate information for a serial connection to the software you're using on your computer.

Indicator Light

The power/proximity LED in the upper right corner of the Super L VI frame is the Indicator Light. It remains off when the power is on. However, when the transducer is in proximity (within the range) of the Active Area, the LED is solid green.

Transducer

Two types of transducers can be used with the Super L VI: pens and cursors. Both are available in corded and cordless versions. The corded transducers get their power from the digitizer. Cordless transducers are powered by batteries. They will go into a battery-saving *Sleep Mode* when no button has been pressed for one to five minutes, depending on the type of transducer being used. To reactivate a sleeping transducer, press one of its buttons.

Cursors

The cursor is similar in appearance to a mouse, except that it has an attached lens with crosshairs for highly accurate detail work. Cursors are available in 4 or 16 button models.

Pens

Each pen is similar in appearance to a ballpoint pen. The pen transducer has three buttons, two on the side of the barrel and one in the pen tip. The pen tip is Button 0 and is used as the pick, or left mouse, button. The lower button is Button 1 and the upper is Button 2.

Preparing the Super L VI

Mounting on a Stand


Visit our Website gtcocalcomp.com to see our Recommended Tilt Stand (Versa Table)



Attaching the Optional Accessory Tray, Plan Holder or Table Feet

Additional T-Nuts have been included in the perimeter mounting channels on the Super L VI frame. You can position the Plan Holder, Table Feet or Accessory Tray where it is most convenient for you by attaching it to any one of the available T-Nuts. The following instructions and the graphic below detail the installation of the Accessory Tray.

Simply slide the Tray Rails into the channel and line up the hole in the tray with the hole in the T-Nut. Tighten the Thumb Screw to secure the Accessory Tray.



Software Configuration

Software drivers provide the communication bridge between your digitizing software application and Super L VI. You should install only the drivers necessary for the Super L VI to work with your application software. If you are not sure which drivers are required, consult with your application vendor.

Configuring Non-Wintab Applications

Many application programs provide configuration information for specific digitizers. If the Super L VI digitizer is not listed, you can use the configuration for the GTCO CalComp Digi-Pad Type 5 or Type 5A (T5/T5A), Roll-Up II, CalComp 3400, DrawingBoard or Summagraphics Microgrid III.

Installing the TabletWorks Driver

Visit our Website: <https://www.gtcocalcomp.com/software-downloads/>




A TabletWorks icon  will display in the System Tray on the Windows Task Bar. Right click on the icon to display the TabletWorks Menu, which provides access to all the TabletWorks features.

Hardware Configuration

When you use the USB interface, no hardware configuration is required. When the optional serial interface is selected, Super L VI must be configured to send data in a format that is compatible with the application software. Different applications have different requirements when interacting with a digitizer. The Super L VI is designed to provide the appropriate serial requirements for a wide variety of graphic, CAD and estimating applications using a simple code system. The SuperSet Menu on the surface of the Super L VI is used to enter the appropriate code for the software being used. A table in *the Using the SuperSet Menu* section of this manual lists the SuperSet Codes for a wide variety of applications.

Determine if you have not already, which communication connection you will be using – USB or the optional serial.




USB Connection

Super L VI USB port connection is USB 1.1 and 2.0 compatible. When the digitizer is connected to the USB port, Windows will recognize that there is a new device connected. If Windows displays the *Found New Hardware* prompt, follow the onscreen instructions to complete the driver installation.

1. Connect the interface cable to the USB jack on the Super L VI Connector Panel. The connector is keyed and will fit only the correct jack. Do not force it. Attach the other end of the USB cable to any one of the USB ports  on your computer or USB hub.



2. Turn the power switch on. The green Indicator Light will begin blinking and the digitizer will beep four short tones, indicating it has power. See the *Super L VI Tones* section for a complete table of the Super L VI tones.



NOTE: Power is supplied through the USB port. No additional power source is needed for this installation.

QuikRuler III™ Connection

The Super L VI has a connection socket for the QuikRuler III. The QuikRuler III is a portable measuring system that quickly and accurately automates blueprint takeoff and drawing measurement processes. Contact GTCO CalComp Sales for price and availability.

Transducer Connection


1. If you are using a corded transducer, connect the cursor or pen to the appropriate jack on the digitizer's Connector Panel. The connector is keyed and will fit only the correct jack. Do not force it.

Optional RS-232 Serial Connection

1. Connect the RS-232 serial cable to the serial jack on the Connector Panel. The connector is keyed and will fit only the correct jack. Do not force it. Attach the 9-pin connector of the serial cable to the serial port on your computer.
2. Plug the power supply into an AC outlet. Connect the power supply to the appropriate jack on the Super L VI Connector Panel. Turn the power switch on. The green Indicator Light will begin blinking and the digitizer will beep four short tones (see the *Super L VI Tones* section for a complete table of Super L VI tones), indicating it has power.



Super L VI Serial Connection



Tablet Power On

The Super L VI power switch is located at the rear of the tablet on the Connector Panel. When turned on, the Super L VI's Indicator Light will begin blinking and four *Success* tones will sound.

If you are using a cordless transducer, turn it on by pressing any button on pen/cursor. The Indicator Light will glow steadily when the transducer is inside the Active Area of the tablet. When the transducer moves outside the Active Area, the Indicator Light will go off.

Using the SuperSet Menu (RS-232 Only)

The SuperSet Menu is the row of buttons printed across the top of the digitizer. It allows you to configure Super L VI to send the appropriate information through an RS-232 serial connection to the software being used on the computer.



The SuperSet Menu is used to prepare the digitizer to receive specific, detailed custom configuration information from the Tablet Configuration Utilities for some serial installations. Use your transducer (pen or cursor) to click on the menu buttons to make your selections.

In addition, for both serial and USB connections, the SuperSet Menu can be used to reset the Super L VI, turn the digitizer alarm OFF or ON, and test the grid or *Active Area*.



The  menu button initiates **Select Mode**. Two-digit numeric codes are entered after Select Mode is activated.

NOTE: The Select Mode will not work with the USB interface. USB digitizers are used exclusively with Wintab drivers.

Most software supports Wintab using the TabletWorks drivers, whose *SuperSet Code* is



on the SuperSet Menu. The Super L VI comes from the factory with the

SuperSet Code  pre-configured.

The  button toggles the digitizer alarm OFF or ON. The  button tests the digitizer grid in the Active Area.

When using the SuperSet Menu, a tone will sound indicating a successful selection when you

click on the  button. Four tones will sound when you select the  button. (See the *Super L VI Tones* section for a complete table of the Super L VI tones.) The number buttons



through  are active only after clicking on the  button to activate Select Mode.

Resetting Super L VI

The Super L VI can be reset by:

- Turning off the power switch on the Controller Connector Panel
- Unplugging and re-plugging the power supply
- Clicking  on the SuperSet Menu.

When one of these events occurs, the Super L VI will revert to the configuration that was last defined. Any remote commands that were active before the reset will be lost.

Turning the Alarm Off and On

You can disable the alarm if you do not want to hear a tone each time the transducer button is pressed. When the alarm is off, you will still hear diagnostic and menu-related tones.



To turn the alarm Off or On:

- Click on the  button to toggle the tones Off or On.

Testing the Active Area

To test the Super L VI grid, or Active Area:

1. Using the transducer, click on the  button to activate the test.
2. Move the transducer around in the Active Area. If there is a break in the grid or the transducer is out of prox, the tablet will beep.
3. Click the  button again to end the test.

NOTE: The following is relevant only when connecting via an RS-232 serial installation. USB does not require configuration.

Configuring Super L VI for Specific Applications

To configure your Super L VI for use with specific applications:

1. In Table 1, find the application program you will be using with your Super L VI. Note the corresponding SuperSet Code.
 - If your application program is not listed in Table 1, find the configuration settings in Table 2 that your application program requires and use the corresponding SuperSet Code.
 - If an appropriate SuperSet Code is not listed in Table 2, then use the Tablet Configuration Utilities to configure your Super L VI.
2. On the SuperSet Menu, click on the  button, and then click on the two digits of the SuperSet Code indicated for your application.

You will hear four short tones after a successful menu configuration.



Table 1: SuperSet Menu Codes for Selected Applications

Program	Company	SuperSet Code
Access	Bautech	39
AccuBid Pro	AccuBid	01
Advanced Construction Estim.	Software Shop Systems	28
A.G.E.	CEIA, Inc.	75
AGTEK Earthwork Engineering (DOS)	AGTEK Development Co.	09
APS	Gunold & Stickma	52
ARC/CAD	ESRI	01
ARC/INFO (DOS)	ESRI	12
ARC/INFO	ESRI	01
ARC/GIS	ESRI	01
ARC/View	ESRI	01
ARCT, ACA		47
ArenaSoft Estimating	Arena Soft	01
ATLAS*DRAW low res	Strategic Locations Planning	07
ATLAS*DRAW high res	Strategic Locations Planning	08
ATLAS GIS	Strategic Mapping	01
AutoCAD	Autodesk, Inc.	01
Autodesk 3D Studio	Autodesk, Inc.	01
AutoSketch	Autodesk, Inc.	01
Autoship	Coastdesign	01
Autoyacht	Coastdesign	01
Autumn	Zenographics	36



Program	Company	SuperSet Code
Batisoft		46
Best Est II	Bird Construction Software	23
Bid Team	Construction Data Control, Inc.	58
Bidpoint	Vertigraph, Inc.	01
Bidworx for DOS	Vertigraph, Inc.	31
Bidworx for Windows	Vertigraph, Inc.	01
BP-340	Barudan America, Inc.	77
BuildNet	Homesphere	09
Buildsoft	Homesphere	09
BuildWare	1SqFt	01
BVH-Gregg Estimating	BVH Gregg Incorporated	04
Cadkey low res	Cadkey	18
Cadkey high res	Cadkey	25
Callidus	Oak Leaf Software	81
Carpet Estimating Systems	Ramco	54
Carlson Takeoff	Carlson Software	01
Civilcad	Bloomfield Computer Services	03
CMS Estimating	Contractor Management Systems	29
CNG Survey	CNG Survey	05
Coastal	Oceanographics	42
Cogo-PC Plus	Civilsoft	01



Program	Company	SuperSet Code
COINS Estimating	Shaker Computer & Management	41
Composer Gold	Building Systems Design	42
Computer Methods Est.	Computer Methods	45
Comquest	Pinnacle Technology	38
Conception 3D	Serbi	22
Construction Link	The Construction Link	04
Contour Plus	Civilsoft	01
Cost Engineer, The	Cost Engineering Technologies	49
Counterpoint	Counterpoint	04
CPS/SP	Radian Corp.	34
Curve Digitizer	West Coast Consultants	33
Cut & Fill (DOS)	Paydirt Systems, Inc.	31
Cut & Fill/Precision (DOS)	Paydirt/Timberline	42
Datacad	Microtexture	14
DATAMINE	Datamine International	82
Deed Mapping System	US Soft Tech	13
DEEM	Met-Coil, Ltd.	69
Design CAD	American Small Business Computers	01
Designer	Micrografix	02
DigiPlus	Civilsoft	01
DigiPro	Prosoft	66
Digitool	Roctek Corp.	24
DigiWin	Prosoft	68
DMS Premiere	Tally Systems	57
DQ 2000	DQ Technologies, Inc.	85
DrawPlus	Micrografix	02



Program	Company	SuperSet Code
Earth Graphics - Deluxe	Earth Graphics	01
Earthwork	Civilsoft	01
Earthwork 3D	AGTEK Development Co.	01
Earthwork Estimating	Ground Rules	01
Earthworks	Tally Systems, Inc.	01
Earthworks (for Windows)	Trakwear	01
-OR-		
Earthworks (for Windows)	Trakwear	56
Easydij EJBIN#4	Geocomp, Ltd.	16
Easydij EJAF#2	Geocomp, Ltd.	35
Easydij EJBIN#30	Geocomp, Ltd.	19
Easy Cad	Easy Cad	01
Eclare	Prosoft, Inc.	66
Edge, The (DOS)	Advanced Estimating	01
Edge, The	Advanced Estimating	01
Equinox	Roctek Corp.	64
ESI 6000 Estimating System	McCormick Systems	09
EST-Duct Estimating	Technical Sales International	01
EST-Mechanical	Technical Sales International	01



Program	Company	SuperSet Code
Estimagic	Estimagic	63
Estimat-All	Safeharbor Software, Inc.	54
Estimate Software	Estimate Software	04
Estimation, Inc. (700 Series)	Estimation, Inc. (Tradepower)	89
Estimation, Inc. (800 & Win Series)	Estimation, Inc. (Tradepower)	88
Execucom	Execucom Systems Corp.	36
Expose	Roctek Corp.	64
Fastcad	Evolution Computing	26
FastPIPE - Gold	FastEST, Inc.	01
Floor Rite	RFMS	01
GAP 01	GTCO CalComp	39
Gemini	Excel	79
Generic CADD	Generic Software, Inc.	01
Geoquest	Softdesk	08
GM-SYS	NW Geophysics Association, Inc.	13
GraphPlus	Micrografix	02
GTCOTEST (default)	GTCO CalComp	01
GTCO WinTab Driver	GTCO CalComp	01
HALO products	Media Cybermetics	13
Hotdij	Geocomp, Ltd.	35



Program	Company	SuperSet Code
Mach Lite	Ziatek, Inc.	04
Mach 2	Ziatek, Inc.	04
Mach 4	Ziatek, Inc.	83
MapGrafix	Comgrafix, Inc.	02
Market America	CACI	11
MasterBuilder (DOS)	Intuit	86
MasterBuilder (2003, 2004)	Intuit	01
Master Touch	Integrated Measurement Systems	35
Measure Mate	Measure Mate (Australia)	01
Measuremate/Measuring Calc.	Paladin Measuring Systems	64
Measure Master	Estimator's Corner	51
Mechanical Construction Manager	Mechanical Professional Services	73
Melco	Melco	78
Metricom	ADII Dynalog	71
Micromine	Micromine Pty., Ltd.	27
Microstation PC	Intergraph Corp.	09
MIKE (DOS)	Comput-Ability, Inc.	68
MIKE	Comput-Ability, Inc.	42
Mirage	Zenographics	36
Molitors & Zimmer	Molitors & Zimmer Estimating Syst.	67
NCE Estimator 2000	National Computer Est., Inc.	01
On Screen Take-Off	OnCenter Software	01



Program	Company	SuperSet Code
Pagemaker	Adobe Systems Inc.	02
PAD	ModaCAD	50
Paydirt Cross-Section (DOS)	Spectra-Physics Laserplan, Inc.	31
Paydirt Roadwork (DOS)	Spectra-Physics Laserplan, Inc.	31
Paydirt Sitework (DOS)	Spectra-Physics Laserplan, Inc.	31
Paydirt Sitework Basic (DOS)	Spectra-Physics Laserplan, Inc.	31
Paydirt Sitework 3.01 for Windows	Spectra-Physics Laserplan, Inc.	05
Paydirt Sitework 3.2 for Windows	Spectra-Physics Laserplan, Inc.	01
Paydirt	Trimble Navigation	01
P-CAD	Personal CAD Systems, Inc.	20
PC.BAT		46
PC Paintbrush	Z Soft	10
PC Paintbrush/Windows	Z Soft	02
PC3D	Jandel Scientific	24
PDS/SHADOW	Polygon Software & Technologies	53
PG01	Hirsch International	22
Phoenix Estimator	Phoenix Estimating	87
Picturemaker	Cubicomp Corp.	15
Piping/DWV Estimating	Esscomate	32
Polynest	Polygon Software	40
Power Takeoff	Ziatek, Inc.	04



Program	Company	SuperSet Code
Precision Estimating/Digitizer (DOS)	Timberline Software	37
Precision Estimating/Digitizer	Timberline Software	01
ProBid	Promation	06
Procad	Teksoft	13
Prodesign II	American Small Bus. Comp., Inc.	01
ProEst Estimating Digitizer Takeoff	CMS	04
ProExcel	Excel	80
Professional Estimating	Enterprise Computer Systems, Inc.	01
PTO	CDCI	58
QED	Roctek Corp.	64
Quest Earthwork	Quest Solutions	01
Quest Estimator	Quest Solutions	01
QuickBid	OnCenter Software	01
QuickCalc	Constructive Computing	58
QuickCALC - Windows	Constructive Computing	01
QuickDirt	Constructive Computing	23
QuickDirt - Windows	Constructive Computing	01
QuickDirt II/QuickEst III	Constructive Computing	58
QuickEst	Constructive Computing	43
QuickEst - Windows	Constructive Computing	01
QuickMeasure	Tally Systems, Inc.	01
QuickPen AutoBid	QuickPen International	04
QuickPen CAD	QuickPen International	09
QuickPen Estimating	QuickPen International	59
QuoteExpress	Quote Software	01



Program	Company	SuperSet Code
Ramco Estimating System	Ramco	54
Remodeling Estimator	National Computer Estimating, Inc.	01
Right Hand Man	Johnston & Associates, Inc.	04
Roadeng	Softree Technical Systems, Inc.	27
Robocad, Robosolid	RoboSystems International	21
Rock-it	Ziatek	04
Roof Cad	True North Estimating Systems	12
Roof Estimator 3000	Essential Technology	65
SDP	Civilsoft	01
Sheetmetal/Ductwork	Esscomate	32
SigmaPlot	Jandel Scientific	24
SigmaScan	Jandel Scientific	24
SiteCalc	Eagle Point	01
Smartcam	Point Control Co.	17
Softplan	Softdesk	08
Sonnet CAD	Interworld Electronics	03
Sonnet Gap	Interworld Electronics	20
Subway	Roctek Corp.	64
Starbid	Geac	29



Program	Company	SuperSet Code
Super-Duct, Super-Pipe	Wendes Mechanical Consulting	48
Surpac	Surpac Mining Systems	27
Takeoff 2000+	Comput-Ability	42
Takeoff Pro	WinEstimator, Inc.	01
TakeoffTool	US Cost	01
Terra Model (DOS)	Plus 3 Software	09
Terramodel	Trimble Navigation	01
Terrasoft	Digital Resource Systems	01
Topographics IIID	CEIA, Inc.	75
Tops II Digitizer	Software Shop Systems	28
TOSCA	Clark University	74
Tradesman	Tradesman Software	01
Turbo Map CAD	U.S. Softtech	01
Versacad	Versacad Corp.	01
Vision	Bidtek	70
Visual Takeoff +	Comput-Ability, Inc.	42
Wall to Wall Estimator	Ramco	11
WenDuct Takeoff	Wendes Systems, Inc.	48
WenPipe	Wendes Systems, Inc.	48
Wilcom Ltd.	Wilcom Ltd.	76
Windows	Microsoft	01
WinEst Pro & WinEst Pro Plus	WinEstimator, Inc.	11
WinEx & WinEx Pro	Roctek Corp.	01
WinMeasure	DeLoach Corporation	01
WinScale	Roctek Corp.	01
2D CAD	West Coast Consultants	33



Table 2: Configuration Details for SuperSet Menu Codes

NOTE: Max = 100 coordinates/second

lpi = lines per inch lpmm = lines per millimeter

Code	Commun.	Output Options	ASCII Options
01	9600,N,8,1	GTCO Binary, 1000 lpi, Cont Max	
02	9600,N,8,1	GTCO Binary, 1000 lpi, Cont Incr	
03	9600,N,8,1	GTCO Binary, 1000 lpi, Cont Max	
04	9600,N,8,1	GTCO Binary, 1000 lpi, Point	
05	9600,N,8,2	GTCO Binary, 1000 lpi, Cont 100	
06	9600,N,8,1	GTCO Binary, 1000 lpi, Point	
07	9600,N,8,1	GTCO Binary, 200 lpi, Cont 100	
08	9600,N,8,1	GTCO Binary, 1000 lpi, Cont 100	
09	9600,N,8,1	GTCO Binary, 1000 lpi, Cont 12	
10	9600,N,8,1	GTCO Binary, 200 lpi, Cont Max	
11	9600,N,8,1	GTCO Binary, 1000 lpi, Cont Max, Alarm	
12	9600,N,8,1	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF
13	9600,N,8,1	GTCO Binary, 1000 lpi, Cont 12	
14	9600,N,8,1	GTCO Binary, 200 lpi, Cont 100	
15	9600,N,8,2	GTCO Binary, 200 lpi, Cont 100	
16	9600,E,7,1	GTCO Binary, 200 lpi, Point	
17	9600,E,7,2	GTCO Binary, 200 lpi, Cont Max	
18	9600,E,7,2	GTCO Binary, 200 lpi, Cont Max	
19	9600,N,8,1	GTCO Binary, 1000 lpi, Point	
20	1200,N,8,1	GTCO Binary, 1000 lpi, Cont 100	



Code	Commun.	Output Options	ASCII Options
21	4800,N,8,1	GTCO Binary, 40 lpmm, Cont 12	
22	4800,N,8,1	GTCO Binary, 1000 lpi, Cont Max	
23	2400,N,8,1	GTCO Binary, 1000 lpi, Cont 12	
24	9600,N,8,2	GTCO Binary, 1000 lpi, Cont Max	
25	9600,N,8,2	GTCO Binary, 1000 lpi, Cont Max	
26	9600,N,8,2	GTCO Binary, 200 lpi, Point	
27	9600,N,8,1	GTCO ASCII, 40 lpmm, Point	Pb, Sp, LF
28	4800,O,7,2	GTCO ASCII, 100 lpi, Point	Sp, CR, LF
29	1200,O,7,2	GTCO ASCII, 1000 lpi, Point	Pb, CR, LF
30	1200,N,8,1	GTCO Binary, 40 lpmm, Cont 12	
31	9600,O,7,2	GTCO ASCII, 1000 lpi, Point	Pb, CR, LF
32	9600,E,7,2	GTCO ASCII, 1000 lpi, Point	Sp, CR
33	2400,E,7,1	GTCO ASCII, 100 lpi, Cont 12	Pb, Sp, CR, LF
34	9600,E,7,1	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF
35	9600,E,7,1	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF
36	9600,E,7,1	GTCO ASCII, 1000 lpi, Cont 12	Sp, CR, LF
37	2400,N,8,1	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF
38	2400,E,7,2	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF
39	1200,O,7,1	GTCO ASCII, 1000 lpi, Cont 12	Pb, CR
40	1200,N,8,1	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF



Code	Commun.	Output Options	ASCII Options
41	9600,E,7,1	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR
42	9600,N,8,1	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF
43	1200,E,7,1	GTCO ASCII, 1000 lpi, Point, Alarm	Pb, Sp, CR
44	9600,N,8,1	GTCO ASCII, 1000 lpi, Cont 12, Alarm	Pb, Sp, CR, LF
45	9600,N,8,2	GTCO ASCII, 100 lpi, Point, Alarm	Pb, CR, LF
46	9600,E,7,2	GTCO Binary, 1000 lpi, Cont 100	
47	9600,O,7,2	GTCO ASCII, 1000 lpi, Cont 100	Pb, CR
48	9600,E,7,1	GTCO ASCII, 1000 lpi, Point	CR, LF
49	1200,E,7,1	GTCO ASCII, 1000 lpi, Cont 12	Pb, CR
50	9600,E,8,1	GTCO ASCII, 40 lpm, Point, Alarm	Pb, Sp, CR, LF
51	1200,N,7,2	GTCO ASCII, 1000 lpi, Point	Pb, CR, LF
52	9600,E,8,1	GTCO Binary, 1000 lpi, Cont 100, Alarm	
53	9600,N,8,1	GTCO ASCII, 1000 lpi, Cont Max	Pb, CR
54	9600,N,8,1	GTCO ASCII, 1000 lpi, Cont 12	Pb, CR
55	9600,O,7,2	GTCO ASCII, 1000 lpi, Cont Max, Alarm	Pb, CR
56	9600,E,7,2	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF
57	9600,O,7,1	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF
58	9600,N,8,1	GTCO ASCII, 1000 lpi, Cont 12	Pb, CR, LF
59	1200,E,7,1	GTCO ASCII, 1000 lpi, Point, Alarm	Pb, Sp, CR
60	9600,O,7,1	GTCO ASCII, 1000 lpi, Point, Alarm	Pb



Code	Commun.	Output Options	ASCII Options
61	4800,N,8,1	GTCO ASCII, 1000 lpi, Point	Pb, CR, LF
62	2400,N,8,1	GTCO ASCII, 1000 lpi, Cont 12	Pb, CR, LF
63	1200,O,7,1	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF
64	9600,N,8,1	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF
65	2400,N,8,1	GTCO Binary, 1000 lpi, Cont 100	
66	9600,O,7,2	GTCO ASCII, 1000 lpi, Point	Pb, Sp, CR, LF
67	9600,N,8,1	GTCO ASCII, 1000 lpi, Cont 12, Alarm	Pb, CR
68	9600,O,7,2	GTCO ASCII, 100 lpi, Point	Pb, Sp, CR, LF
69	9600,E,7,1	GTCO ASCII, 40 lpmm, Point	CR, LF
70	1200,N,8,1	GTCO ASCII, 100 lpi, Point, Max, Alarm	Sp, CR
71	9600,N,8,1	GTCO Binary, 40 lpmm, Cont	
72	1200,O,7,2	GTCO ASCII, 100 lpi, Point	Pb, Sp, CR, LF
73	9600,N,8,1	GTCO ASCII, 1000 lpi, Point	CR, LF
74	9600,N,8,1	GTCO ASCII, 1000 lpi, Cont 100, Alarm	Pb, Sp, CR, LF
75	9600,N,8,1	Calcomp ASCII 3, 1000 lpi, Point	CR
76	9600,N,8,1	Summa ASCII 2, 10 lpmm, Point	CR
77	9600,N,8,1	Summa ASCII 2, 10 lpmm, Cont 100	CR
78	2400,N,8,1	Summa Binary, 10 lpmm, Point	
79	9600,O,7,2	Summa ASCII 1, 10 lpmm, Cont 100	LF
80	9600,O,8,1	Summa Binary, 10 lpmm, Point, Alarm	
81	9600,E,7,2	Summa ASCII UIOF, 40 lpmm, Point	CR, LF, Decimal
82	9600,N,8,1	GTCO ASCII, 1000 lpi, Point, Max, Alarm	Pb, Sp, CR, LF
83	9600,N,8,1	GTCO ASCII, 1000 lpi, Cont Incr	Pb, Sp, CR
84	9600,N,8,1	GTCO ASCII, 1000 lpi, Point	Pb, LF
85	9600,N,8,1	Summa ASCII UIOF, 1000 lpi, Point	Pb, LF



Code	Commun.	Output Options	ASCII Options
86	*Special		
87	*Special		
88	*Special		
89	*Special		
90-98		User configuration storage locations	
99	9600,N,8,1	GTCO Binary, 1000 lpi, Cont Max	

***86-89 require special firmware to activate.**



Super L VI Tones

The Super L VI produces an alarm in the form of audio tones to inform you of various events. The table below describes the kinds of tones you might hear while operating the digitizer.

Table 3: Super L VI Tones

Length	Number of times	Meaning
Short	Four at power up	Diagnostics passed
Short	Four	Successful end of menu mode
Short	Once	Transducer switch pressed, if the alarm tone is enabled
Medium	Three	Alarm tone toggles On/Off
Medium	Three at power up	Configuration error*
Long	Three	SuperSet Code aborted
Continuously on	At power up	Diagnostics failed*

Short = 1/16 second

Medium = 1/4 second

Long = 1/2 second

***Configuration error tones** or **Diagnostics failed tones** indicate a serious problem. If you hear either of these tones, call GTCO CalComp Technical Support at 800.220.1137 or visit gtcocalcomp.com.

NOTE: You might hear tones produced by the Super L VI which are actually sent by your application program. (Programs can send commands to the digitizer to turn the audio tone generator on and off.) If you hear tones during digitizing and they do not correspond to the tones listed in the table above, they are produced by the application program.

Introduction to the Tablet Configuration Utilities

The Super L VI with its Controller uses the Tablet Configuration Utilities to control baud rate, data format and other operating characteristics for the RS-232 interface. It is used to relay configuration information to the Super L VI in cases where Table 1 and Table 2 do not supply the information or a SuperSet Menu Code for the graphic application software being used.

The configuration parameters for the Super L VI are divided into three categories:



- Communication Options
- Output Format Options
- Mode Options

Communication Options

- **Baud:** The rate, in bits/second, at which characters are transmitted across the RS-232C serial interface. Choices are: 1200, 2400, 4800, 9600, 19200 or 38400.
- **Data Bits:** Data bits represent the actual data being sent from one device to another. Both devices must be set for the same number of data bits. Choices are: Seven (7) or Eight (8).
- **Stop Bits:** Each character has one or two stop bits, which tell the receiving device that a character is complete. The number of stop bits usually does not matter. Setting for two stop bits instead of one may overcome a mismatch in parity or data bits. Choices are: One (1) or Two (2).
- **Parity:** One bit can be allocated for parity (parity is a simple error-detecting scheme). Both devices (sending and receiving) must be set for the same parity – either odd parity or even parity – or they must be set for no parity. Choices are: None (N), Even (E) or Odd (O).

Output Format Options

- **GTCO:** Selects GTCO-compatible formats. Choices are: Binary or ASCII.
- **CalComp:** Selects CalComp-compatible formats. Choices are: Binary, ASCII 1, ASCII 2, ASCII 3 or ASCII 4.
- **Summa:** Selects Summagraphics-compatible formats. Choices are: Binary or ASCII.

ASCII formats can be modified by including or excluding a button code, decimal point, carriage return or line feed, depending on whether GTCO, CalComp or Summa formats have been selected.

- **Button:** Defines whether the Pushbutton (Pb) value is included in the ASCII output report. This option is available only with GTCO formats. Choices are: Include or Exclude.
- **Space:** Defines whether the Space (Sp) character (hex 20) is included in the ASCII output report as a delimiter between the X and Y coordinate values. This option is available only in GTCO formats. Choices are: Include or Exclude.



- **Decimal:** Defines whether the period character (hex 2E) is included in the ASCII output report between the units and tenths digits. This option is available only in Summagraphics formats. Choices are: Include or Exclude.
- **Return:** Defines whether the Carriage Return (CR) character (hex 0D) is included in the ASCII output report as a terminator. This option is available in GTCO and Summagraphics formats. Choices are: Include or Exclude.
- **Line Feed:** Defines whether the Line Feed (LF) character (hex 0A) is included in the ASCII output report as a terminator. This option is available in GTCO, CalComp and Summagraphics formats. Choices are: Include or Exclude.

Mode Options

- **Mode:** Defines how output reports are sent from the digitizer. Choices are: Point, Line, Continuous, Line Incremental or Continuous Incremental.
- **Rate:** Determines how fast output reports will be transmitted from the digitizer. Choices are: 12, 50 or 100 reports per second.
- **Resolution:** The smallest reported value returned by the digitizer. Choices are: 1000 lpi, 2000 lpi, 4000 lpi, 40 lpmm, 100 lpmm or 150 lpmm.

Using the Tablet Configuration Utilities

If your application is not represented in the SuperSet Menu and does not have a SuperSet Code or if a different configuration is required, you can use the Tablet Configuration Utilities to structure the Super L VI. The Tablet Configuration Utilities replace the 24 switches that were associated with older GTCO CalComp digitizers and the Custom Configuration Menu Card used with the Super L II Plus.

To Configure the Super L VI with the Tablet Configuration Utilities:

1. Make sure the Super L VI is plugged into a Serial Port, powered on and all the tablet drivers have been uninstalled or disabled.
2. Install the Tablet Configuration Utilities from our Website www.gtcocalcomp.com.
3. After installation is complete, run the *Tablet Configuration Utilities* from the **Programs** list under GTCO CalComp TCU.



4. The Tablet Configuration Utilities will begin searching the Serial Ports for a supported tablet.
 - a. If the tablet is found, information about the tablet will display under **Device Info** near the bottom of the screen.
 - b. If the tablet is not found, a message will appear under **Device Info** near the bottom of the screen.
 - i. If Wintab files were found, it is possible that the TabletWorks driver has the Serial Port open.
 - ii. If the Serial Port is open by another application, it will not be displayed under **System Info**. Close any application or uninstall any driver that is using the Serial Port and select *Refresh System Info* from the **File** dropdown list at the top of the screen. Click on the Serial Port icon under **System Info** to search that Serial Port.

NOTE: The Tablet Configuration Utilities can use the TabletWorks driver to test the tablet, but it must be communicating directly with the tablet, via the Serial Port, in order to configure it.

5. Once the Super L VI has been found on a Serial Port, select *Advanced Configuration* from the **Options** dropdown list at the top of the screen.
 - a. If Advanced Configuration is not an option, make sure *Wintab Compatible Driver* is not listed under **Device Info**.
6. Select a predefined   through  , SuperSet Code, or select one of the User Defined   through  , SuperSet Codes to customize.
 - a. User Defined (  through  ) SuperSet Codes are initially read from the tablet when the Advanced Configuration screen opens. This is to prevent loss of custom settings. Selecting **Read Current Settings** from the Options menu will:
 - i. Read the Power-Up settings and User Defined SuperSet Codes from the tablet.
 - ii. Overwrite all Custom Settings not yet saved to the tablet.
 - b. **Restore Factory Settings** from the Options menu will prompt for:
 - i. Power-Up settings reset to factory default and set current.
 - ii. User Defined SuperSet Codes cleared and reset to factory default.
7. After making your selections, choose one of the following from the **File** menu at the top of the screen.
 - a. **Save Temporary Settings** will configure the tablet as shown until the tablet is powered off, reset or another SuperSet Code is selected.
 - i. After saving temporary settings, select **File/Exit** to test with other applications. This will leave the tablet configured to the temporary



settings selected and close the Serial Port, enabling other applications to communicate with the tablet.

- b. **Save Power-Up Settings** will configure the tablet as shown. Every time the tablet is powered off and back on or reset, it will restore these settings.
- c. **Save Custom Settings** will reconfigure all nine of the tablet's User Defined SuperSet Codes to the settings specified in the corresponding SuperSet Code dropdown list.
 - i. You can click on the SuperSet Menu buttons on the tablet using the tablet's cursor to activate these configurations:

 plus   through  .

- 8. When you have finished, select *Exit* or *Close* from the **File** menu.
 - a. Exit will close the Tablet Configuration Utilities.
 - b. Close will exit the Advanced Configuration Screen and return to the Tablet Configuration Utilities window.

Learning the Basics

You will find that using your Super L VI tablet is as easy or easier, than using a mouse.

Super L VI transducers are more accurate than a mouse, giving you greater control over your movements.

Using the Transducer

The transducer does not need to be in contact with the tablet surface in order for the tablet to sense its presence. It can be detected up to 1/2" above the Active Area. When the transducer is in the zone above the surface of the digitizer, it is referred to as being *in prox*. The Indicator Light will go from a blinking green light to a solid green light when the transducer is in prox of, or touching, the tablet's surface. The in prox zone allows you to trace through materials placed on the digitizer's surface, such as drawing or a book. Before using the transducer, be sure that *Sleep Mode* is turned off by pressing a button, or in the case of the pen, touching the tip of the tablet's surface.

Using the Cursor

When you use the cursor, the intersection point of the crosshairs on the lens identifies the point you are selecting. The crosshairs are etched on the bottom of the lens to increase accuracy. For maximum precision, look through the lens from a position directly over it.

Button 0 (4B/16B), or the yellow button (diamond Layout), is used as the pick, or left mouse, button. All other buttons are defined by the TabletWorks software, or through your own software application.



Using the Pen

There are two variations of pens: the Cordless click tip and Corded Click Tip. On both pens, the pen tip is Button 0 and is used as the pick, or left mouse, button. The lower side button is Button 1 and the upper side button is Button 2. To use the pen, press down until you feel the tip click. It is primarily used for tracing and menu picking.

The functions these buttons provide are defined through the TabletWorks software, or through your own software application.

Learning Basic Movements

Clicking and Double-Clicking

Clicking is the action of making a selection. You may be selecting a key on the digitizer surface or making a selection from your computer monitor. To click, place the transducer or move the screen pointer using the transducer, to the item to be selected. Tap the pen or press Button 0 on the cursor. A double-click requires you to quickly tap the pen or press the button two times, while the tool remains in the same place. You can also double-click by pressing the pen or cursor button that has been defined as a double-click button.

Dragging

Dragging is the action of moving the transducer during a selection. To drag, click on an object, but instead of lifting the pen tip or releasing the cursor button, hold it down while moving the transducer, or corresponding object on the screen, to the desired new location.

Caring for the Tablet and Transducer

Follow these precautions at all times to avoid damaging your Super L VI:

- Avoid discharging static electricity to the tablet.
- Do not place heavy objects on the tablet surface.
- Do not use sharp objects; such as compasses or knives, on the tablet surface.
- Do not use the tablet surface for any purpose other than drawing, tracing or digitizing.
- Do not drill holes on any part of the digitizer or controller.

Cleaning the Tablet

To clean the tablet's surface, use a soft, non-abrasive cloth. Hardened dirt can be removed with a slightly dampened cloth. Do not clean pencil lines with a soft cleanser or pencil eraser. This could create an undesirable shiny spot on the tablet's surface that cannot be removed.



Do not use abrasive cleaners, acrylic, or lacquer paint thinners – or cleansers with an acetone or solvent base, such as MDC or EDC – on the tablet surface. They will damage the tablet.

Cleaning the Cursor

To clean the cursor body, use a mild cleanser. Do not spray the cleanser directly on the cursor – instead, dampen a soft cloth with a mixture of water and the cleanser. Clean the cursor reticles with alcohol.



Excessive cleaning can dissolve the filled black crosshair on a reticle.

Replacing the Pen Tip

To replace the pen tip, grasp the tip and pull straight out (see figure). Insert the new tip and press until it clicks into place.



Replacing the Cordless Pen Batteries

The pen requires two 393 silver oxide batteries. The average battery life is 200 hours.




Do not use ZINC AIR batteries as replacement batteries. They will corrode the electronics of the pen.



To replace the batteries:

1. Unscrew the pen cap. Hold the pen from the bottom and gently slide off the pen cover to expose the batteries.
2. Remove the old batteries by turning the pen over and gently tapping it, letting the batteries fall into your other hand.
3. Insert the new batteries as they are shown in the figure above (+ towards pen tip).
4. Replace the pen cover and screw the pen cap onto the pen.




Replacing the Cordless Cursor Batteries

The cordless cursor requires two AAA batteries. The average battery life for the cursor batteries is 2,000 hours.

To replace the batteries:

1. Place the cursor face down in the palm of your hand. Use a Phillips screwdriver to remove the two screws located on the bottom of the cursor (see figure). Remove the cursor base.
2. Remove the old batteries from the battery casings.
3. Place the new batteries in the casings, matching the polarity of each battery with the markings on the connector strips (match + to +).

Reposition the cursor base. Replace the screws with the Phillips screwdriver.



Troubleshooting Guide

GTCO CalComp wants your experience with Super L VI to be a successful one. If you ever encounter a problem, please follow the steps below:

1. ***Install properly first.***

This troubleshooting guide assumes you have already correctly installed your Super L VI according to the detailed instructions in the *Installing Your Super L VI* section. If you have not followed the step-by-step instructions in that section, do so now.

Read the topics below to check for a solution to your problem. Work through the troubleshooting flowcharts on the following pages in this troubleshooting guide.

Record any unusual observations. Your notes will be useful if you need assistance from GTCO CalComp.



2. If your system still doesn't work.

Call GTCO CalComp Technical Support at 800.220.1137 (in the U.S. or Canada) or visit us at gtcocalcomp.com

Outside the U.S. or Canada, contact your local GTCO CalComp dealer.

Be prepared to discuss the observations you made while troubleshooting.

Tablet Checklist

- Is the tablet power supply (used only with the serial connection to the computer) plugged into the digitizer and into a live outlet?
- Is the tablet power switch on?
- Does the Indicator Light glow steadily when the transducer is in prox inside the Active Area? Does the Indicator LED go out when the transducer is outside the Active Area?
- The Indicator Light will be off if the transducer has gone into Sleep Mode. Press any button on the transducer to activate it. If the transducer is in the Active Area and the Indicator Light remains off, change the transducer's battery.
- Are all cable connections seated properly?
- Is the communications cable (either USB or serial) connected to both the digitizer and the computer? Check that the cable is connected to the serial port specified in your software package.
- Is the transducer cable connected to the digitizer?
- Is the tablet set up according to the software recommendations?
- Are any of the connector cables or receptacles damaged? Check for bent pins, cut insulation and loose wires.

Computer Checklist

- Is the computer plugged into a live outlet? Did you turn on the computer?
- Does the computer work with any of your software? Try one of your other programs.
- Is your software package installed correctly?
- If your communications connection is USB, does the USB port work? If serial, does the serial port work? The only way to test the port without special equipment is to reinstall something that has worked in the past and see if it still works.
- Have there been any recent electrical storms in your area that may have damaged your equipment?



Software Checklist

Does the tablet work with some software?

If your tablet currently works with some software packages, you know that the tablet, USB or serial port and computer work.

- Even if the software package you are trying to install and the software that is working both support the same tablets, it does not always mean that you can use the same tablet settings. The output format may be the same, but the communications protocol, resolution, operating mode and data rate may be different. Check your software's requirements.
- Call the software manufacturer. Perhaps the software package has a problem with another component of your system.

Did the software work in the past?

If the software package worked with the tablet in the past, then the problem lies with the new set up.

- Check all the connectors. Is the tablet still plugged into the same port? If yes, reset the tablet by unplugging and re-plugging the power supply and restart the software.
- Did you reset or power down the computer?
- During reset and power on, the computer can send meaningless characters out the serial port and this can disable the tablet. Reset the tablet again.
- Have you installed any new software or hardware? Remove it from your system and see if the problem goes away.
- Did you move any cables?
- If you are using a PC, did the new software alter your AUTOEXEC.BAT file?
- Have you updated the software or its drivers?
- Are you loading another mouse driver?
- Did you reinstall the software, perhaps after a problem with your hard drive? Double check your installation procedure and the driver you selected.
- Reinstall the software from its master. The program files may have been corrupted.



Troubleshooting Chart


The following table lists common Super L VI problems, their causes and their solutions.

Problem	Cause	Solution
Frozen screen pointer	Transducer is in Sleep Mode.	Press any button on the transducer.
	Tablet plugged into the wrong serial port on the computer.	Is the serial port being used correctly identified in your software application? Check that the power cable is installed correctly.
	Tablet not powered correctly. Batteries low in transducer.	Replace the batteries in the transducer.
	Software application set up incorrectly.	Check that the tablet is identified in your software application.
	Another device is connected to a COM port that shares the same IRQ as the tablet COM port (<i>i.e.</i> , your tablet is connected to COM1 IRQ4 and your modem is connected to COM3 IRQ4).	Move one of the devices to another COM port. Contact your system manufacturer for assistance in relocating the device.
	Tablet is set too close to the screen monitor.	Move the tablet farther away from the screen.
Unable to use the entire tablet surface	Incorrect format selected.	Check your selections in the Software application.
	Software application set up incorrectly.	Check that the tablet is identified in your software application.
Intermittent issue using Cordless Pointer	Lines jump, can't pic area	Check lighting/bad ballast




Procedure A: Begin Troubleshooting

NOTE: This procedure should only be used to troubleshoot serial connections.





Procedure B: Troubleshooting





Returning your Tablet for Repair (Out of Warranty)

If you believe you have a defective tablet, first see all topics in this section (above) and visit our website at www.gtcocalcomp.com, support@gtcocalcomp.com or call 800.220.1137.

Technical Support will assist you in determining if your tablet is defective and will help you obtain a Return Merchandise Authorization (RMA) number. **Important:** Please do not return your product without first discussing the issue with, and receiving an RMA from Technical Support.

You must pay any shipping charges to ship the product to GTCO CalComp.

Repackaging for Shipment

Whenever you ship electronic equipment, try to ship it in its original packing materials.

Place a copy of the RMA in with your Item(s) you are returning and write the RMA number on the package

Regulatory Statements and Warranty

Radio and Television Interference

The user is cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Reorient or coil cables.
- Consult the dealer or an experienced Radio/TV technician for help.



NOTE: Any cables the user adds to the device must be shielded to be in compliance with the FCC standards. Any unauthorized modification to this device could result in the revocation of the end user's authority to operate this device.

Canada

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of the Canadian Department of Communications.

Le present appareil numérique n'émet pas bruits radioélectriques dépassant les limites applicables aux appareils numériques de Classe B prescrites dans le règlement sur le brouillage radioélectrique édicté par le Ministère des Communications du Canada.

Japan



この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB 情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。
取扱説明書に従って正しい取り扱いをして下さい。

European Union Emission Directive

This product is in conformity with the protection requirements of EU Council Directive 89/366/ECC on the approximation of the laws of the Member States relating to electromagnetic compatibility.

This product has been tested and found to comply with the limits for Class B Information Technology Equipment according to CISPR 22/European Standard EN55022. The limits for Class B equipment were derived for typical industrial environments to provide reasonable protection against interference with licensed communication devices.



European Union WEEE Directive

The manufacture of this equipment required the extraction and use of natural resources. It may contain hazardous substances that could impact health and the environment.

- In order to avoid the dissemination of the hazardous substances into the environment and to diminish the pressure on our natural resources, GTCO CalComp encourages you to return this product to the appropriate take-back system facility. These facilities reuse or recycle most of the materials in this equipment in a responsible way.
- The crossed-out wheeled bin symbol below invites you to use these take-back systems.
- If you need more information about the collection, reuse and recycling systems in your area, please contact your local or regional waste authority.
- Further information about the responsible end-of-life management of this and other GTCO CalComp products is available on our website at www.gtcocalcomp.com.



Bescheinigung des Herstellers/Importeurs

Heirmit wird bescheinigt, dass der/die/das

Super L VI

(Geraet, Typ, Bezeichnung)

im Uebereinstimmung mit den Bestimmungen der

Vfg 1046/1984

(Amtsblattverfuegung)

Funk-Entstort ist.

Der Deutschen Bundespost wurde das Inverkehrbringen dieses Geraetes angezeigt und die Berechtigung zur Ueberpruefung der Serie auf Einhaltung der Bestimmungen eingeräumt.

GTCO CalComp by Turning Technologies, Inc.

(Name des Herstellers/Importeurs)

Dieses Geraet wurde einzeln sowohl als auch in einer Anlage, die einen normalen Anwendungsfall nachbildet, auf die Einhaltung der Funkentstoerbestimmungen geprueft. Es ist jodoch moeglich, dass die Funkentstoerbestimmungen unter unguenstigen Umstaenden bei anderen Geraetekombinationen nicht eingehalten werden. Fuer die Einhaltung der Funk-entstoerbestimmungen seiner gesamten Anlage, in der dieses Geraet betrieben wird, ist der Betreiber verantwortlich. Einhaltung mit betreffenden Bestimmungen kommt darauf an, dass geschirmte Ausfuehrungen gebraucht werden. Fuer die beschaffung richtiger Ausfuehrungen ist der Betreiber verantwortllich.



Limited Warranty for Super L VI

GTCO CalComp warrants these products to be free from defects in material and workmanship under the following terms.

Coverage

Parts and labor are warranted for two (2) years from the date of the first consumer purchase for the digitizer tablet, controller, transducers and tablet accessories. Power supply and cables are also warranted for one (1) year. This warranty applies to the **original consumer purchaser only**.

Within the European Union, the warranty period is two (2) years, as mandated by the EU. Contact your local dealer or distributor for additional warranty information.

A nominal Diagnostic Fee will be charged after 2 years of use and calculated from the date of original consumer purchase or Digitizer Serial Number.

Conditions

Except as specified below, this warranty covers all defects in material or workmanship in the products. The following are not covered by the warranty:

1. Any product on which the serial number has been defaced, modified or removed (if applicable).
2. Damage, deterioration or malfunction resulting from:
 - a. Accident, misuse, abuse, neglect, fire, water, lightning or other acts of nature, unauthorized modification for any purpose, unauthorized product modification, or failure to follow instructions supplied with the product.
 - b. Repair or attempted repair by anyone not authorized by GTCO CalComp.
 - c. Any damage in shipment of the product (claims must be presented to the carrier).
 - d. Any other cause which does not relate to a manufacturing defect.
3. Any product not sold by an Authorized Dealer of GTCO-CALCOMP.

GTCO CalComp will pay all labor and material expenses for covered items, but will not pay for the following:

1. Removal or installation charges.
2. Costs for initial technical adjustments (set up), including adjustment of user controls.
3. Certain shipping charges. (Payment of shipping charges is discussed in the next section of this warranty.)
4. Packaging costs. (Customers should keep their boxes.)

Warranty Service Procedures

1. To obtain service on your GTCO CalComp contact the Technical Support Department to receive a Return Material Authorization Number (RMA#) and shipping instructions by calling: 800.220.1137 or visit gtcocalcomp.com



2. Ship the product to GTCO CalComp with the RMA# marked clearly on the outside of the box. Without a clearly marked RMA# on the shipping box, GTCO CalComp reserves the right to refuse the shipment.
3. Although you must pay any shipping charges to ship the product to GTCO CalComp for warranty service, GTCO CalComp will pay the return shipping charges for ground shipment. Other shipping options are available at an additional fee.
4. If GTCO CalComp determines that the unit is not defective within the terms of the warranty, the consumer shall pay the cost of all freight charges, as well as any repair charges.

Technical Support

Web-based Technical Support is available free of charge at: www.gtcocalcomp.com

Technical Support is available free of charge to the original consumer. Please contact our Technical Support Department at: 800.220.1137.

Disclaimer of Unstated Warranties

The warranty printed above is the only warranty applicable to this purchase. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. Assuming the warranty above stated is otherwise applicable, it is expressly understood and agreed that GTCO CalComp sole liability whether in contract, tort, under any warranty, in negligence or other shall be for the repair or replacement of the defective parts and under no circumstances shall GTCO CalComp be liable for special, indirect or consequential damages. The price stated and paid for the equipment is a consideration in limiting GTCO CalComp liability.

Notice

Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state, or province to province.



Corporate Headquarters
14557 N. 82nd Street
Scottsdale, Arizona 85260
Sales and Support: 800.220.1137

www.gtcocalcomp.com

SUPER L VI™

Copyright© 2014 GTCO CalComp by Turning Technologies, Inc.
Super L VI is a trademark of GTCO CalComp by Turning Technologies, Inc.
All other products and company names are the trademarks or registered trademarks of their
respective owners.

The information contained in this document is subject to change without notice. GTCO CalComp by Turning Technologies assumes no responsibility for technical, or editorial errors, or omissions that may appear in this document, or for the use of this material. Nor does GTCO CalComp by Turning Technologies make any commitment to update the information contained in this document. This document contains proprietary information which is protected by copyright. All rights reserved. No part of this document can be photocopied or reproduced in any form without the prior, written consent of GTCO CalComp by Turning Technologies, Inc.

36-01241 / 37-01102-01 Rev. E