











# How To Set/Clear Student ID

**First Time Users:** You must set your Student ID before joining a RF Class and using your PRS Clicker to transmit Responses.

- 1 Power on your Clicker.
- 2 When autoscan begins, press  to stop it.
- 3 Press  to display the **Setup Menu**.
- 4 Scroll  or  to display the **ID:** menu option.  
Press  to select it.
- 5 Input your Student ID. Press  to backspace to clear any characters in this field. If your Student ID contains alpha characters, refer to the instructions below for entering alpha characters.
- 6 Press  to save your Student ID.

## Entering Alpha Characters:

- 1 Press one of the letter keys  to switch to Alpha Mode and display the selected alpha character on the LCD screen.
- 2 Use the   keys to scroll to the letter you want to input.  
For each letter you want to input, you must press a letter key to go into Alpha Mode.